


PD9300

Battery Selection Procedure

Battery Type Selector

Color	Type
Green	FLA - Flooded Lead Acid
White	AGM - Absorbed Glass Material
Blue	Lithium - LiFePO4
Magenta	Constant Voltage 13.6 VDC

Chart 1



Insert the CLAW into the hole for the Selector Button just to the left of the Battery Type Indicator LED. Press and hold the button for at least 3 second until the LED changes color. Continue to hold until the desired battery type is indicated. (See Chart 1 above) Remove the CLAW when the LED indicates the proper battery type.

Notes*

1. Flooded Lead Acid (GREEN) is the Factory Default.
2. Use only with the battery type as selected by the chart.
3. The LED will illuminate for 30 seconds after the last button press. The LED will illuminate after pressing the button or reapplying AC power or battery.